NETCHANGE(5)

NAME

netchange - format of netchange files read by irsim.

DESCRIPTION

A netchange file consists of a series of lines, each of which begins with a key letter. The key letter beginning a line determines how the remainder of the line is interpreted. The following are the list of key letters understood.

any text

Lines beginning with a vertical bar are treated as comments and ignored by the program.

add type gate source drain length width [area]

Add a new transistor of type to the network.

Currently, type may be:

- n n-channel enhancement transistor.
- p p-channel enhancement transistor.
- d depletion transistor (for NMOS).

The names of the nodes to which the gate, source, and drain of the transistor are connected are given by gate, source, and drain respectively. The length and width of the transistor are given by length and width respectively. The area parameter, if given, will use that number as the area for calculating the gate capacitance. Length and width should be given in lambda units, area should be in lambda² units, these will internally be multiplied by the LAMBDA factor from the configuration (.prm) file.

delete type gate source drain length width [area]

Delete an existing transistor from the net. All the parameters have the same meaning as for the add command.

move type gate source drain length width [area] g s d
Move an existing transistor to a new location the net.
type, gate, source, drain, length, width, have the same
meaning as for the add command. g, s, and d are the
names of nodes to which the gate, source and drain
should be connected. If a particular terminal(s) is
not to be re-connected, the name can be specified using
an "*". Any or all of g, s, and d may be "*". For
example, to move the gate of an n-channel transistor
from node old to new the following command would be
used:

m n old src node drn node 4 2.2 new * *

Note that the drain and source terminals, and the g and s terminals are interchangeable; the simulator will

know if these are swapped. So the last example could also have been written:

m n old drn_node src_node 4 2.2 new * *

capacitance node value

Change the capacitance of a node by value picofarads. Value may be negative, thereby decreasing the node's capacitance. Node is the node name.

N node metal-area poly-area diff-area diff-perimeter Change the capacitance of node using the area and perimeter information of the metal, polysilicon, and diffusion layers. All the parameters should be in lambda (or lambda^2 for areas) units, they will internally be converted to the appropriate capacitance as defined in the configuration file. The values can be negative to decrease the capacitance.

M node M2A M2P MA MP PA PP DA DP PDA PDP Change the capacitance of node, using the following geometrical information:

M2A area of 2nd-level metal

M2P perimeter of 2nd-level metal

MA area of 1st-level metal

MP perimeter of 1st-level metal

PA area of polysilicon

PP perimeter of polysilicon

DA area of n-diffusion

DP perimeter of n-diffusion

PDA area of p-diffusion

PDP perimeter of p-diffusion

All perimeter values should be in lambda units, area values should be in lambda^2 units. The perimeter measures are half of the actual total perimeter (i.e., they are the sum of the lengths of the top and one side). Again, the values may be negative to decrease the capacitance of the node.

threshold node low high

Change the threhsold voltages of node. Low and high should be in normalized voltage units (i.e. floating-point numbers in the range 0.0 to 1.0).

Delay node tplh tphl

Change the delays for node to be tplh nanoseconds for low-to-high transistions, and tphl ns. for high-to-low transistions. These should be absolute numbers, not relative increments/dercrements.

NOTE: For all commands, only the first letter is significant, the rest of the string will be ignored. They are only shown here for clarity.

BUGS

This is an experimental interface for the incremental simulator and is very likely to change in the future.

SEE ALSO

irsim(5) sim(5) presim(1)